

Chapter 1 Overview

Package Checklist	1-1
The VA-503A Mainboard	1-2
Main Features	1-3
Intelligent Properties	1-5
ACPI Ready	1-6

Chapter 2 Installation Procedures

1). Set System Switches/Jumpers	2-1
Jumpers	2-1
Quick Reference (Jumpers)	2-2
Quick Reference (Connectors)	2-3
Clear Password: CPW	2-5
Flash ROM Type Selection: EP1, EP2	2-5
Power Supply Type Selection: PWR	2-6
2). Install RAM Modules	2-6
SDRAM Memory	2-6
Install and Remove DIMMs	2-7
Cache Memory	2-8
3). Install the CPU	2-9
CPU/SDRAM/AGP Frequency Selection: S2-4/-5.../-10	2-10
CPU to Bus Frequency Ratio: S2-1/-2/-3	2-10
CPU Voltage Selection: S1-1/-2/.../-5	2-11
4). Install Expansion Cards	2-12
Audio Riser Card (optional)	2-13
5). Connect Cables and Power Supply	2-14
AT Keyboard Connector: AT_KB	2-14
Serial Port Connectors: COM1, COM2	2-14
Universal Serial Bus Connectors: USB1, USB2	2-15
CPU Fan Connector: CPU_FAN	2-16
Printer Connector: LPT	2-16
Floppy Diskette Drive Connector: FDD	2-17
Remote Power Connector: RPW_CON	2-17
IDE HDD Device Connectors: PRIMARY, SECONDARY ..	2-18
ATX Power Connector: POWER	2-18
Chassis Fan Connector: CHAS_FAN	2-18

Standard Power Supply Connector: POWER	2-19
Infrared Connector: IR	2-20
Chassis Intrusion Alarm Connector: CHASSIS	2-20
Front Panel Block Connector	2-21

Chapter 3 BIOS Setup

CMOS Setup Utility	3-1
Standard CMOS Setup	3-2
Hard Disk Configurations	3-2
Software Turbo Speed	3-3
BIOS Features Setup	3-3
Chipset Features Setup	3-6
Power Management Setup	3-9
PNP/PCI Configuration	3-13
Load BIOS Defaults	3-15
Load Setup Defaults	3-16
Integrated Peripherals	3-16
Supervisor/User Password	3-21
IDE HDD Auto Detection	3-22
Save and Exit Setup	3-22
Exit without Saving	3-22